

# Nanoptix PayCheck™ NextGen

# Firmware Upgrading & Recovery Instructions

Nanoptix Inc Dieppe, NB, Canada E1A 1P6 1-888-983-3030 <u>www.Nanoptix.com</u>

Date: July 4 2023 Document#: 700014-0000 Rev 1.6

### Section 1: USB Setup and Installation



- 1. For specific firmware requests please contact <a href="mailto:support@nanoptix.com">support@nanoptix.com</a> to receive a download link to the firmware.
- 2. Download the firmware to a <u>known location</u> on your local disk.
- 3. Prepare the USB flash drive by inserting it into one of your computer's USB ports.
- 4. Format the USB flash drive using a <u>FAT32</u> file system, set the allocation unit size to the default setting and **change the volume label to "NPXUSBDNLD**"

Format NPXUSBDNLD (G:)
Cagacity:
7.45 GB
<u>File</u> system
FAT32 (Default)
Allocation unit size
Default allocation size
Restore <u>d</u> evice defaults Volume [abel
NPXUSBDNLD
Format options   Quick Format   Create an MS-DOS startup disk
<u>Start</u> <u>Close</u>

5. Extract the whole content of the ".zip" file that contains the firmware, provided by Nanoptix, to the USB flash drive that was prepared in step 4.

Edit View Tools	Help						
janize 🔻 Extract all	files						(
Favorites	Name	Туре	Compressed size	Password	Size		
	Firmware Release Description.pdf	PDF Document	117 KB	No			135
Libraries	Nextgen_Paycheck_Standard_NGP-2.00C.ndb	NDB File	83,837 KB	No		192,	287
Documents	settings.txt	Text Document	2 KB	No			4
			×				
Extract Compress	ed (Zipped) Folders						
	ca (Lipped) i olacio						
	ca (cipped) i olacis						
Select a Destinat	ion and Extract Files						
Select a Destinat	ion and Extract Files						
Select a Destinat	tion and Extract Files						
Select a Destinat Files will be extracted D:\	tion and Extract Files	Browse					
Select a Destinat Files will be extracted D:\	to this folder:	Browse					
Select a Destinat Files will be extracted D:\	to this folder:	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder:	Browse					
Select a Destinat Files will be extracted D:\ V Show extracted file	tion and Extract Files to this folder: :s when complete	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder: 25 when complete	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder: 25 when complete	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder: :s when complete	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder: :s when complete	Browse					
Select a Destinat Files will be extracted D:\	tion and Extract Files to this folder: es when complete	Browse					
Select a Destinal Files will be extracted D:\	tion and Extract Files to this folder: es when complete	Browse					
Select a Destinal Files will be extracted D:\	tion and Extract Files to this folder: es when complete	Browse					

6. Make sure the PayCheck<sup>™</sup> NextGen printer is <u>OFF</u> then Insert the USB flash drive in the front USB port (Or in the side USB ports if available).

#### NOTE: If the firmware needs to be restored using a micro SD card, go to section 2





7. Plug in the printer to turn it <u>ON</u>.

- 8. On power up, the red LED will be illuminated, after 15 seconds, the download will start. As confirmation, the printer will emit a beeping sound at approximately a 1 second interval and the green LED will blink at the same speed.
- Since only the sections of firmware that change will be downloaded, the process takes anywhere between 1 second and 6 minutes. Once complete, the speed of the LED and beeping will increase to 3 times per second.
- 10. Once the rapid beeping is heard, the USB flash drive can be removed. The printer will reset and boot up with the newly downloaded version of firmware. This process takes approximately 20 seconds; the illumination of the green LED is a confirmation that the printer is ready. <u>Note:</u> Do not disconnect power or communication until the download is complete.
- 11. As verification a *power on test ticket* can be printed. To print the test ticket, <u>the printer must be</u> <u>powered "ON" while holding the paper feed button for up to 15 seconds</u>. A status ticket similar to below will be printed. Pressing the button again will result in blank tickets. This ticket can be used to verify the *firmware version*.

Model:	PAYCHECK NextGen
Firmware:	NPG-9.99Z (0x6D00)
Printer Driver Ver:	1.0.1.1
SETTINGS	
COMMUNICATION	
Protocol:	NTL
Interface:	Serial
Serila Settings:	9600,8,NONE
Handshaking:	XON + RTS
Print mode:	Page
NETWORKING	
eth0	99.99.99.201
PRINT CONTROL	
Speed:	200 mm/sec
BurnTime:	300 uS
Motor Current:	58%
PRINTER ENVIRONMENTAL CONDITIO	NS
Voltage:	24.7 Volts
Temperature:	25 Celcius
SYSTEM RESOURCES	
FLASH Used=00000	
Free=65535	
LIBRARY INVENTORY (Satandard)	
Tpl: 0, 1, 2, 4, 4, 5,6,7,8,9,A,B	
Rgn 1, 2, 3, 4, 5, 6, 7, 8, h, 9, A, B, C, D, B	Ξ, F,
G, I, J, K, L, N, O, P, Q, R, S, T, U, Z	, X, a,
b, c, d, e, f, g, l, j, k, l, m, n, o, p, q	
Gfx:	
LIBRARY INFORMATION	
Board:	209022-0001R-04
Board ID:	5P00122
Printer ID:	NG0003C
Date Code:	20160505
*S 0 PAY-4.82H @ @ @ I @ P *	

### Section 2: Restoring printer's firmware

- A micro SD is required in order to complete the process. The storage capacity of the card must be between 512MB and 32GB
- Balena's Etcher Utility is required in order to prepare the micro SD card. The Balena's Etcher Utility software can be downloaded from <u>https://www.balena.io/etcher/</u>

NOTE: When going from any NGP-1.XYZ to NGP-2.XYZ firmware release the download may result in the printer's download mode beeping to get stuck in either the ON or OFF state. Removing the USB flash drive early can result in the printer failing to reboot, and requiring the use of a MicroSD card to recover.

Please read the following guide for detailed instructions and examples. http://techsupport.nanoptix.com/techsupport/files/nextgen/docs/help/index.html

- 1. Visit <u>http://techsupport.nanoptix.com/techsupport/files/nextgen/recovery/MicroSDBootDisk\_BOT-</u> <u>3.20A.zip</u> for the recovery image.
- 2. Download the .img file to a known location on your local disk.
- 3. With the Paycheck NextGen powered off.
- 4. Insert the micro SD card in your card reader and note which drive letter is associated with the micro SD card when it's connected. (Example "G:"). Then start the Etcher Utility software.
- 5. Navigate to and select the image file that was downloaded previously in step 4. Select the Device that corresponds to the Micro SD card that was inserted in step 5.



- 6. Click the Flash! button, when prompted about overwriting the disk, click yes. Once complete, eject the micro SD card.
- 7. On the underside of the Printer put dip Switch 1 into the ON position. This will force the Printer to boot from the Micro SD recovery card. Dip switch 4 should set to the OFF position, this will prevent the watchdog from resetting the printer while the download is in process.



- 8. Insert the micro SD recovery card into the micro SD slot on the front of the printer. And insert the Nanoptix USB download drive (USB flash drive created in section 1) into the Front USB Host port of the printer.
- Power on the printer, the red LED will be illuminated, after 15 seconds, the download will start. As confirmation, the printer will emit a beeping sound at approximately a one second interval and the green LED will blink at the same speed.
- 10. The process takes anywhere between 1 second to 6 minutes. Once complete, the speed of the LED and beep will increase to 3 times per second. At that point, disconnect the printer and remove the USB flash drive and micro SD cards. Restore dip switch 1 to the OFF position and dip switch 4 to ON
- 11. Plug in the printer and verify the firmware downloaded correctly.